



« **DC -- Mass Air Flow (MAF) Sensor** »

**Pre-Diagnostic Information**  
(Warnings, schematics, etc.)

<b>Mass Air Flow (MAF) Sensor</b>	<b>Pinpoint Test</b>	<b>DC</b>
-----------------------------------	----------------------	-----------

---

## **DC1 DIAGNOSTIC TROUBLE CODE (DTC) 26/159: CHECK VPWR CIRCUIT VOLTAGE**

---

DTC 26/159 indicates that the Mass Air Flow (MAF) sensor is out of Self-Test range and that the MAF Signal was greater than .70 volts during Key On, Engine Off Self-Test. Engine Running DTC 26/159 indicates that the MAF Signal was not between .20 and 1.50 volts during Key On Engine Running Self-Test.

NOTE:

**DTC 26/159 could be generated by the garage exhaust ventilation system. Remove ventilation system and properly vent to outside atmosphere. Rerun KOEO Self-Test.**

Possible causes:

- Damaged Idle Air Control (IAC) solenoid.
- Damaged MAF sensor.
- MAF sensor partially connected.
- Damaged Powertrain Control Module (PCM).
- Air leak before or after MAF sensor.
- **Is DTC 12/13/411/412 present?**

**Yes**

**For DTC 13/411:**

GO to «[KE15](#)».

**For DTC 12/412:**

GO to «[KE1](#)».

**No**

GO to «[DC2](#)».

---



« [DC](#) -- [Mass Air Flow \(MAF\) Sensor](#) »

Pre-Diagnostic Information  
(Warnings, schematics, etc.)

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	---------------	----

---

## DC2 CHECK VPWR CIRCUIT VOLTAGE

---

- Key off.
- Disconnect MAF sensor.
- Key on, engine off.
- Measure voltage between VPWR circuit at the MAF sensor vehicle harness connector and battery negative post.
- **Is voltage greater than 10.5 volts?**

### Yes

GO to [«DC3»](#).

### No

SERVICE open in VPWR circuit.  
RERUN [«Quick Test»](#).

---



« **DC -- Mass Air Flow (MAF) Sensor** »

**Pre-Diagnostic Information**  
[Warnings, schematics, etc.]

<b>Mass Air Flow (MAF) Sensor</b>	<b>Pinpoint Test</b>	<b>DC</b>
-----------------------------------	----------------------	-----------

---

## **DC3 CHECK MAF SENSOR GROUND**

---

- Key on, engine off.
- MAF sensor disconnected.
- Measure voltage between VPWR circuit and PWR GND circuit at the MAF sensor vehicle harness connector.
- **Is voltage greater than 10.5 volts?**

**Yes**

GO to «[DC13](#)».

**No**

SERVICE open PWR GND circuit.  
RECONNECT MAF sensor.  
RERUN «[Quick Test](#)».

---



« **DC -- Mass Air Flow (MAF) Sensor** »

**Pre-Diagnostic Information**  
(Warnings, schematics, etc.)

<b>Mass Air Flow (MAF) Sensor</b>	<b>Pinpoint Test</b>	<b>DC</b>
-----------------------------------	----------------------	-----------

---

## **DC13 DIAGNOSTIC TROUBLE CODE (DTC) 66/157 OR 72/129: AIR LEAK AT MAF SENSOR**

---

Engine Running DTC 72/129 indicates insufficient MAF change during Dynamic Response Test.

Possible causes:

- Open MAF circuit.
- Open VPWR circuit to MAF sensor.
- Open PWR GND circuit to MAF sensor.
- Open MAF RTN circuit to MAF sensor.
- MAF circuit shorted to ground.
- Damaged Powertrain Control Module (PCM).
- Damaged MAF sensor.
- Air leak before or after MAF sensor.
- MAF sensor disconnected.
- Idle Air Control (IAC) system failure (at closed throttle position).
- Check for broken/loose air outlet tube clamps (throttle body and air cleaner assembly ends), cracks/holes in air outlet tube, worn gaskets between MAF sensor and air cleaner assembly (including intermediate tube on 3.8L SFI Taurus/Sable and 3.8L Continental).

- **Is a fault indicated?**

**Yes**

SERVICE as necessary.  
RECONNECT all components.  
RERUN «[Quick Test](#)».

**No**

GO to «[DC14](#)».

---



**Pre-Diagnostic Information**  
(Warnings, schematics, etc.)

<b>Mass Air Flow (MAF) Sensor</b>	<b>Pinpoint Test</b>	<b>DC</b>
-----------------------------------	----------------------	-----------

---

## **DC14 CHECK CONTINUITY OF MAF AND VPWR CIRCUITS**

---

- Key off.
- Disconnect MAF sensor.
- Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary.
- Install breakout box, leave PCM disconnected.
- Measure resistance between VPWR circuit at the MAF sensor vehicle harness connector and Test Pins 37 and 57 at the breakout box.

**For MFI vehicles:**

- Measure resistance between MAF circuit at the MAF sensor vehicle harness connector and Test Pin 14 at the breakout box.

**For SFI vehicles:**

- Measure resistance between MAF circuit at the MAF sensor vehicle harness connector and Test Pin 50 at the breakout box.
- **Is each resistance less than 5.0 ohms?**

**Yes**

GO to «DC15».

**No**

SERVICE open circuit.  
REMOVE breakout box.  
RECONNECT all components.  
RERUN «Quick Test».

---



« **DC -- Mass Air Flow (MAF) Sensor** »

**Pre-Diagnostic Information**  
(Warnings, schematics, etc.)

<b>Mass Air Flow (MAF) Sensor</b>	<b>Pinpoint Test</b>	<b>DC</b>
-----------------------------------	----------------------	-----------

---

## **DC15 CHECK MAF CIRCUIT FOR SHORTS TO GROUND AND MAF RTN CIRCUIT**

---

- Key off.
- MAF sensor disconnected.
- Breakout box installed, PCM disconnected.

### **For MFI vehicles**

- Measure resistance between Test Pin 14 and Test Pins 15, 40 and 60 at the breakout box.

### **For SFI vehicles:**

- Measure resistance between Test Pin 50 and Test Pins 9, 40 and 60 at the breakout box.
- **Is each resistance greater than 10,000 ohms?**

### **Yes**

GO to [«DC16»](#).

### **No**

SERVICE short circuit(s).  
REMOVE breakout box.  
RECONNECT all components.  
RERUN [«Quick Test»](#).

---



« [DC](#) -- [Mass Air Flow \(MAF\) Sensor](#) »

Pre-Diagnostic Information  
(Warnings, schematics, etc.)

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	---------------	----

---

## DC16 CHECK PWR GND CIRCUIT CONTINUITY

---

- Key off.
- MAF sensor disconnected.
- Breakout box installed, PCM disconnected.
- Measure resistance between PWR GND circuit at the MAF sensor vehicle harness connector and battery negative post.
- **Is resistance less than 10 ohms?**

### Yes

GO to [«DC17»](#).

### No

SERVICE open circuit.  
REMOVE breakout box.  
RECONNECT all components.  
RERUN [«Quick Test»](#).

---



« [DC](#) -- [Mass Air Flow \(MAF\) Sensor](#) »

Pre-Diagnostic Information  
(Warnings, schematics, etc.)

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	------------------	----

---

## DC17 CHECK MAF RTN CIRCUIT CONTINUITY

---

- Key off.
- MAF sensor disconnected.
- Breakout box installed, PCM disconnected.

**For MFI vehicles:**

- Measure resistance between MAF RTN circuit at the MAF sensor vehicle harness connector and Test Pin 15 at the breakout box.

**For SFI vehicles:**

- Measure resistance between MAF RTN circuit at the MAF sensor vehicle harness connector and Test Pin 9 at the breakout box.
- **Is resistance less than 5.0 ohms?**

**Yes**

GO to [«DC18»](#).

**No**

SERVICE open circuit.  
REMOVE breakout box.  
RECONNECT all components.  
RERUN [«Quick Test»](#).

---



Pre-Diagnostic Information  
(Warnings, schematics, etc.)

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	---------------	----

---

## DC18 CHECK MAF CIRCUIT FOR SHORT TO GROUND

---

- Key off.
- MAF sensor disconnected.
- Breakout box installed.
- Connect PCM to breakout box.

**For MFI vehicles:**

- Measure resistance between Test Pin 14 and Test Pins 15, 40 and 60 at the breakout box.

**For SFI vehicles:**

- Measure resistance between Test Pin 50 and Test Pins 9, 40 and 60 at the breakout box.
- **Is each resistance greater than 10,000 ohms?**

**Yes**

GO to [«DC19»](#).

**No**

REPLACE PCM.  
REMOVE breakout box.  
RECONNECT MAF sensor.  
RERUN [«Quick Test»](#).

---



« [DC](#) -- [Mass Air Flow \(MAF\) Sensor](#) »

Pre-Diagnostic Information  
[Warnings, schematics, etc.]

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	------------------	----

---

## DC19 CHECK MAF CIRCUIT OUTPUT

---

- Key off.
- Reconnect MAF sensor.
- Breakout box installed, PCM connected.
- Key on, engine running.

**For MFI vehicles:**

- Measure voltage between Test Pin 14 at the breakout box and negative battery post.

**For SFI vehicles:**

- Measure voltage between Test Pin 50 at the breakout box and negative battery post.
- **Is voltage between .36 and 1.50 volts?**

**Yes**

GO to [«DC20»](#).

**No**

REPLACE MAF sensor assembly.  
REMOVE breakout box.  
RECONNECT PCM.  
RERUN [«Quick Test»](#).

---



Pre-Diagnostic Information  
[Warnings, schematics, etc.]

Mass Air Flow (MAF) Sensor	Pinpoint Test	DC
----------------------------	---------------	----

---

## DC20 CHECK MAF CIRCUIT OUTPUT

---

- Key off.
- Reconnect MAF sensor.
- Breakout box installed, PCM connected.
- Key on, engine running.

**For MFI vehicles:**

- Measure voltage between Test Pin 14 and Test Pin 15 at the breakout box.

**For SFI vehicles:**

- Measure voltage between Test Pin 50 and Test Pin 9 at the breakout box.
- **Is voltage between 0.36 and 1.50 volts?**

**Yes**

REPLACE PCM.  
REMOVE breakout box.  
RERUN «[Quick Test](#)».

**No**

REPLACE MAF sensor.  
REMOVE breakout box.  
RECONNECT PCM.  
RERUN «[Quick Test](#)».

---