

[Log In](#) [Contact Us](#)

SHOPPING CART: 0 Items

[HOME](#)[OUR PRODUCTS](#)[OUR BRANDS](#)[PRO CENTER](#)[REGISTER](#)[RELATED LINKS](#)**Catalog Results / 1998 Lincoln Navigator** 5.4L - 8Cyl[Need Help Finding a Part?](#)[View Shopping Cart](#)**You Have Selected** [Change Vehicle](#)

Vehicle: 1998 Lincoln Navigator
Category: Not Selected
Sub-Category: Sensors
Engine Base: 5.4L - 8Cyl

Search 1998 Lincoln Navigator by:

Keyword

Part Number

Categories[Accessories and Fluids](#)[Air and Fuel Delivery](#)[Body](#)[Brake](#)[Cooling](#)[Driveline and Axles](#)[Electrical, Charging and Starting](#)[Electrical, Lighting and Body](#)[Electronics and Telematics](#)[Emission Control](#)[Engine](#)[Exhaust](#)[HVAC](#)[Hardware and Service Supplies](#)[Ignition](#)[Steering](#)[Suspension](#)[Tire and Wheel](#)[Tools and Equipment](#)[Transfer Case](#)[Transmission](#)[Transmission and Transaxle - Automatic](#)[Wiper and Washer](#)**Sub-Categories**[Cooling Fan, Clutch and Motor](#)[Gaskets and Sealing Systems](#)[Hoses and Pipes](#)[Radiators, Coolers and Related Components](#)[Sensors](#)[Thermostat, Gasket, and Housing](#)[Water Pump and Related Components](#)**Your Search Results****5 Parts found for 1998 Lincoln Navigator > [Cooling](#) > [Sensors](#)** [Print](#)

Show per page: 10

Page 1

Image	Part Number	Part Name and Description	Price (MSRP/List)	Your Price	Availability	Quantity
	12A648	Engine Coolant Temperature Sensor 5.4L; For readout sensor use F3VY 12A647-A; Rectangular connector with 2 flat pins	Call	Select a dealer for prices & availability		<input type="text"/>
						+ Add To Cart
	12A648 (DY-681)	Engine Coolant Temperature Sensor 5.4L; Ambient temperature sensor for engine control; Rounded connector with 2 round pins	Call	Select a dealer for prices & availability		<input type="text"/>
						+ Add To Cart
	12A648 (DY-719)	Engine Coolant Temperature Sensor 5.4L; Rectangular connector with 2 flat pins	Call	Select a dealer for prices & availability		<input type="text"/>
						+ Add To Cart
	12A671	Engine Coolant Temperature Sensor And Adapter 5.4L; Water temp sender with threaded adaptor that has water tube on side.	Call	Select a dealer for prices & availability		<input type="text"/>
						+ Add To Cart
	12A671	Engine Coolant Temperature Sensor And Adapter Water temp sender with threaded adaptor that has water tube on side.	Call	Select a dealer for prices & availability		<input type="text"/>
						+ Add To Cart

[Print](#)

Show per page: 10

Page 1

[View Shopping Cart](#)

Need Help Finding a Part?

OUR BRANDS**SITE FEATURES**[Search Catalog](#)[Our Products](#)[Industry News](#)[Live Chat](#)[Enter Invitation Code](#)[Video Tutorials](#)[Español](#)**MY PROFILE**[Log In](#)[Select Dealer](#)[Register](#)**FORD MOTOR COMPANY**[Ford Vehicles](#)[Lincoln Vehicles](#)[Contact Ford](#)[Racing](#)[Warriors in Pink](#)[The Ford Story](#)

[©2012 Ford Motor Company](#) [Site Map](#) [FAQ](#) [Site Feedback](#) [Contact Us](#) [Privacy](#) [Your CA Privacy Rights](#)

powered by  | **OECconnection**

